



1 kürzere Schraube und ein kürzerer Spacer

**Die restlichen Schrauben und Spacer sind etwas länger.
Das große Ablageträger-Blech wird als letztes angeschraubt, das kann erst einmal zur Seite gelegt werden.**



Als erstes werden die Seitenteile und das flache Blech am Fahrzeug angeschraubt.

Bei den beiden Seitenteilen gibt es ein linkes und ein rechtes Teil, die "Aussparung" für das Trengitter zeigt in Fahrtrichtung nach vorne, bei den beiden flachen Blechen gibt es keinen Unterschied zwischen rechts und links.

Direkt ans Fahrzeug kommt der Spacer, dann das flache Blech, dann das Seitenteil.

(Auf diesem Bild ist die Aussparung nicht zu sehen, da es sich um das alte Modell handelt)



Die Schrauben bitte noch nicht final festziehen, die Seitenteile sollen sich noch bewegen lassen. Wenn beide Seitenteile angeschraubt wurden kann man das Ablageblech dazwischen schrauben, also die kurzen Schrauben einfädeln, Unterlegscheiben nicht vergessen, Stopmuttern draufdrehen und fest anziehen. Zum Schluss dann die Schrauben der Seitenteile fest anziehen, FERTIG!



1 shorter screw and one shorter spacer

The remaining screws and spacers are slightly longer.
The large shelf support plate is screwed on last, this can be
be put to one side for the time being.



The first step is to screw the side panels and the flat plate are screwed onto the vehicle.
The two side panels have a left and a right side.
right part, the "recess" for the partition grille points forwards in the direction of travel, with the two flat panels there is no difference between right and left.
The spacer comes directly on the vehicle, then the flat plate, then the side panel.
(The recess cannot be seen in this picture as this is the old it is the old model)



Please do not finally tighten the screws yet,
The side panels should still be able to move.
When both side panels have been screwed on
the storage tray between them,
the short screws, thread in the washers
not forget the washers, screw on the stop nuts and
tighten and tighten. Finally, tighten the screws of the
tighten the screws on the side panels, DONE!